



Latitude E6520: Visual Guide to your Computer

Guide to ports locations and external features of your Latitude E6520 system.

Table of Contents:

- 1. Front View
- 2. Rear View
- 3. Top View
- 4. Bottom View
- 5. Left View
- 6. Right View

1. Front View



	Chassis Front View Features
1.	Built in Microphone - Used to capture audio sounds
2.	Built in Camera - Used to capture moving images and snapshots. (Optional)
3.	Display
4.	Power Button - Press to turn on the laptop or exit a power management mode.
5.	Keyboard
6.	Fingerprint Scanner - Security feature to identify the user using fingerprints.
7.	Contactless Smart Card Reader
8.	Media Card Reader - Provides a fast and convenient way to view and share digital photos, music and videos stored on a media card.

	Chassis Front View Features
9.	Touch Pad - Allows the user to adjust the system audio volume.
10.	Volume Controls - Allows the user to adjust the system audio volume.
11.	Device Status LED's - Indicates power on/off and shows battery status.

[Back to Top](#)

2. Rear View



	Chassis Rear Feature
1.	RJ-45 (Network) Connector - Used to make ethernet connections.
2.	Kensington Lock Slot - Used to attach a commercially available antitheft device to the laptop.
3.	Modem Connector (RJ-11) - Used to connect the laptop to a network via a modem. If modem is not purchased, it will be installed with the modem port plug.
4.	AC Adapter Connection - Used to connect an AC adapter to the computer.
5.	USB 2.0 Connector - Used to connect USB devices, such as flash memory, a mouse, keyboard or printer.

[Back to Top](#)


3. Top View



	Chassis Top Features
1.	Power / HDD LED - Indicates system power and hard drive activity.

[Back to Top](#)

4 Bottom View



Contact us

Chassis Bottom Features
1. Battery - Lithium-ion Battery
2. Docking Port - Used for connecting the laptop to a docking station and slice battery.
3. Battery Release Latches - Lock the battery into the device.
4. Country of Origin (CCO) Label - Contain model name and country made info.
5. Water Drainage Slot - For draining water that falls on keyboard.
6. Speakers - Sound output.

[Back to Top](#)

5. Left View



Chassis Left Features
1. VGA External Monitor Port - Used to connect an external monitor to the computer.
2. USB 2.0 Connector - Used for connecting with USB devices.
3. Headphone / Microphone Combo Jack - Used to connect audio peripherals. Attach a headphone, speaker or microphone to the connector.
4. Smart Card Slot - Used for inserting Smart Card into the system.
5. Hard Drive - Stores data and programs used by the system.

[Back to Top](#)

6. Right View



Chassis Right Features
1. Express Card Slot - Used for inserting Express Cards into the system.
2. Optical Drive - Used to read from and write to optical disc media.
3. Wireless Switch - Enables or Disables wireless connections on the system.
4. IEEE 1394 Connector - Used for making high-speed connections with 1394 devices.

	Chassis Right Features
5.	USB 2.0 Connector - Used to connect USB devices, such as flash memory, a mouse, keyboard or printer.
6.	eSATA / USB 2.0 Connector - Used to connect external SATA hard drives or USB devices.
7.	HDMI Port - For connecting with high definition graphics devices.

[Back to Top](#)

If you require further assistance or wish to give us feedback, please engage our technical team on [Twitter](https://twitter.com/DellCaresPro) (<https://twitter.com/DellCaresPro>).

[Tweet](#) [Follow](#) [⌵](#)

Article ID: SLN285432

Last Date Modified: 12/24/2019 03:46 AM

Contact us